
# **OPERATION MANUAL**





- RCM-1250C
- RCM-1250C AB
- RCM-16C
- RCM-16C AB



© MAXON Lift Corp. 2009

#### KEEP THIS MANUAL IN CAB OF VEHICLE

Register your liftgate online at www.maxonlift.com/htm/services/reg.htm. For a free copy of other manuals that pertain to these liftgate models, please visit our website at www.maxonlift.com or contact customer service at (800) 227-4116.

# **TABLE OF CONTENTS**

WARNINGS	4
LIFTGATE TERMINOLOGY	5
ATTACH DECALS	6
FORKLIFT ADVISORY	7
OPERATION	8


### **A** WARNING

 Incorrect operation of this Liftgate can result in serious personal injury. Comply with WARNINGS and Liftgate operating instructions in this manual. Do not allow untrained persons to operate the Liftgate. If you need to replace an Operation Manual, additional copies are available from:


> MAXON Lift Corp. Customer Service 11921 Slauson Ave Santa Fe Springs, CA 90670 (800) 227-4116

- 2. Do not exceed rated load capacity of the Liftgates which is 1,250 lbs. for models RCM-1250C and RCM-1250C AB, and 1,600 lbs. for models RCM-16C and RCM-16C AB.
- 3. Do not allow any part of your body to be placed under, within, or around any portion of the moving Liftgate or its mechanisms, or in a position that would trap them between the platform and the floor of truck body (or between platform and the ground) when Liftgate is operated.
- 4. Consider the safety and location of bystanders and location of nearby objects when operating the Liftgate. Stand to one side of platform while operating the Liftgate. Be certain that the area the Liftgate will move through during operation is clear of all obstacles.
- 5. Comply with all attached instruction decals and warning decals.
- 6. Keep decals clean and legible. If decals are illegible or missing, have them replaced. **Get free replacement decals from Maxon.**
- 7. Never drive a forklift on the Liftgate platform.
- 8. Do not move vehicle unless Liftgate is correctly stowed.
- 9. Correctly stow platform when not in use. Extended platforms could create a hazard for people and vehicles passing by.
- 10. A correctly installed Liftgate will operate smoothly and reasonably quiet. The only noticeable noise, during Liftgate operation, is from the power unit while the platform is being opened (SD models only), lowered (power down models only), raised, or closed. Listen for scraping, grating and binding noises and have the problem corrected before continuing to operate the Liftgate.
- 11. Above all, **USE GOOD COMMON SENSE** when operating this Liftgate.
- 12. Never use a cell phone while operating the Liftgate.

## LIFTGATE TERMINOLOGY




#### **DECALS**



# **FORKLIFT ADVISORY**

# WARNING Keep forklift OFF of platform.




### **OPERATION**


# **A** WARNING

Never operate control switch while unfolding platform.


Standing to the side of platform (FIG. 8-1A), push
 UP on handle to release platform (FIG. 8-1B). Unfold the platform as shown in FIG. 8-1A.



2. Unfold the flipover (FIG. 8-2).



 Push the toggle switch to DOWN position as shown in FIG. 9-1B. Lower the Liftgate until it touches the ground (FIG. 9-1A).




### **OPERATION - Continued**

# **A WARNING**

A load should never extend past the edges of the platform. Do not place unstable loads on platform and do not allow load to exceed lifting capacity of Liftgate. If standing on platform, do not allow your feet to extend beyond inboard edge of platform.

4. Load the platform at ground level and bed level as follows. Place all loads as close as possible to the inboard edge of the platform with heaviest part toward the truck body as shown in FIG. 10-1. If you need to stand on platform with the load, stand in the footprint area shown and comply with the preceding WARNING.



## WARNING

Never move the vehicle unless the Liftgate is properly stowed.

5. Before moving the vehicle, prepare the Liftgate as follows. Remove load from platform. If the platform is at ground level, push the control switch to the UP position as shown in FIG. 10-2B. Release the control switch when platform is all the way up (FIG. 10-2A).






FIG. 10-2A

6. Fold the flipover as shown in FIG. 11-1.



FOLDING FLIPOVER FIG. 11-1

7. Fold platform until it locks in place (FIG. 11-2).



FOLDING PLATFORM FIG. 11-2

8. Liftgate is ready for transport.